



coachsmart



One bike
computer –
countless
possibilities

A small and easy to use bike computer with a battery capacity of over 300 hours and enormous customizability. You decide what data you want to be displayed, choosing from a wide variety of ANT+ sensors and precise data from your smartphone.



coachsmart



CONTENTS

1. <u>Setup</u>	S. 4-7
2. <u>Buttons and display</u>	S. 8-10
3. <u>Managing the menus</u>	S. 11- 22
4. <u>Navigation</u>	S. 23-25



coachsmart



1. SETUP

Racing, City, Trekking, Mountain...
The **coach**smart's variety of features
and add-ons offer the perfect
configuration for your purpose.




THE ADD-ONS

The **coachsmart** is a true all-rounder. It can connect to all common ANT+ sensors and it can also communicate with all electronic gears, E-bikes and smartphones. Its features are nearly unlimited in their customizability so that every biker can find their perfect setup

PAIRING WITH ANT+ SENSORS

The pairing starts automatically by inserting the battery or by pressing the AC-button at the back of the **coachsmart**.





PAIRING WITH ANT+ SENSORS

This Video
shows a
detailed
description of
the pairing-
process

(English captions
available)

2. BUTTONS AND DISPLAY

Easy handling with just three buttons

THE BUTTONS



Bike



E-bike



DISPLAY

The information displayed changes depending on what type of bike the **coachsmart** is connected to.



3. MANAGING THE MENUS

The **coachsmart** offers a variety of customizability of display and setup

Configuration of the lower display area

Example: displaying power

MODE



Power



Sub-
menus



bAt
Battery
capacity
of the
Power-
meter



Runtime
since
last
battery
change



Button presses:

long ● press


short ● press



MENU- STRUCTURE

A **long press** of the (M) button switches from the main mode to the sub menus.

A **short press** of the (M) button switches between the sub menus.

With a repeated **long press** of the (M) button in a sub menu various customizations can be made

The Configuration is identical in all further
sub menus*:

Travel time -
Heart rate -
Power -
Display of Power – Balance -
Gear display -
Battery information -
Distance -

*as long as the
corresponding
sensors are
connected

Configuration of the lower display area

Travel Time

MODE	<div> <div>L</div> <div>R</div> <div>DISTANCE</div> <div>TRAVEL TIME</div> </div>	
	<div> <div>No Sub-menu available</div> </div>	

MENU-STRUCTURE

The **upper-right** display shows the **current speed**, the lower display area can show various interchangeable modes. Every mode has various sub-menus with various display setups.

Button presses:

long  press


short  press



*as long as the corresponding sensors are connected

Configuration of the lower display area

Heart rate



Button presses :

long ● press

short ● press




MENU-STRUCTURE

The **upper-right** display shows the **current speed**, the lower display area can show various interchangeable modes. Every mode has various sub-menus with various display setups.

*as long as the corresponding sensors are connected

Configuration of the lower display area

Power



Button presses :

long ● press
↓

short ● press

--->


MENU-STRUCTURE

The **upper-right** display shows the **current speed**, the lower display area can show various interchangeable modes. Every mode has various sub-menus with various display setups.

*as long as the corresponding sensors are connected

Configuration of the lower display area

Display of Power-Balance

MODE		
	Shows the power's left-right ratio (in%)	
Sub-menus	No Sub-Menu available	

Button presses :

long  press

short  press

MENU-STRUCTURE

The **upper-right** display shows the **current speed**, the lower display area can show various interchangeable modes. Every mode has various sub-menus with various display setups.

*as long as the corresponding sensors are connected

Configuration of the lower display area

Gear display

MODE	<div data-bbox="253 194 755 396"> <div data-bbox="415 194 511 282"> L ▶ </div> <div data-bbox="465 194 511 282"> R ▶ </div> <div data-bbox="253 297 421 396">POWER-BALANCE</div> <div data-bbox="490 297 755 396">GEAR DISPLAY</div> </div> <div data-bbox="1078 287 1433 439">Shows the current gear of the electronic gearshift (left: Chainring right: Pinion)</div>
Sub-menus	<div data-bbox="479 458 614 554">No Sub-Menu available</div>

MENU-STRUCTURE

The **upper-right** display shows the **current speed**, the lower display area can show various interchangeable modes. Every mode has various sub-menus with various display setups.

Button presses :

long ● press
↓

short ● press




*as long as the corresponding sensors are connected

Configuration of the lower display area		
Battery capacity		
MODE	<div> <div>L</div> <div>R</div> <div>GEAR DISPLAY</div> <div>BATTERY CAPACITY</div> </div> <div>Shows the E-Bike's or electronic gearshift's battery capacity.</div>	
Sub-menus	No Sub-Menu available	

MENU-STRUCTURE

The **upper-right** display shows the **current speed**, the lower display area can show various interchangeable modes. Every mode has various sub-menus with various display setups.


Button presses :



*as long as the corresponding sensors are connected

Configuration of the lower display area

Distance



Button presses :

long ● press

short ● press

· · · · ·

MENU-STRUCTURE

The **upper-right** display shows the **current speed**, the lower display area can show various interchangeable modes. Every mode has various sub-menus with various display setups.

*as long as the corresponding sensors are connected



Our
suggestion
for
advanced
athletes

MENU- STRUCTURE

When connecting the **coachsmart** with both a cadence sensor and a power meter, the upper display area will display **cadence** (instead of speed) and the lower display area will display your **current power**.

Displaying Heart rate and Power simultaneously



Our
suggestion
for
competitive
athletes

MENU- STRUCTURE

When connecting the **coachsmart** with both a heart rate sensor and a power meter, the upper display area will display heart rate (instead of speed) and the lower display area will display your current power.

4. NAVIGATION

Transform the **coachsmart** into a navigation device using the naviki App



Turn your phone into
a bike navigation device

NAVIGATION USING THE naviki APP

- **Perfect route-planning and navigation** with a smartphone app
- **Maximal accuracy** when determining your position
- **Precise altitude-measurement** by comparing GPS, cartographic data and your smartphone's **barometric sensor***
- **Power savings** thanks to disabled smartphone display
- Display all vital routing-information **directly on your coachsmart**

Get the naviki app's navigation advice for a one-time purchase
3,79€ on Android,
3,99€ on iOS.

*Depends on the smartphone's hardware. smartphones equipped with barometric sensor include iPhone 5 and newer, Samsung Galaxy S3 And newer.



Turn your phone into
a bike navigation device

NAVIGATION USING THE naviki APP

In addition to
the routing-
data the
naviki app
lets you
display
following
information:

Speed-
Distance-
Altitude-
Current time -
Travel time-

Making the
coachsmart
useable
without any
sensors.



NAVIGATION

This video shows the usage of the **coachsmart** together with the naviki app.
(English captions available)

ORDER NOW
coachsmart
www.o-synce-shop.de





IMPRINT:

Momes Gmbh
Handschuhsheimer Landstr. 27
69120 Heidelberg
Germany
E-Mail: shop@o-synce.com
Tel. +49 (0) 6221 657 289 0

VAT-NO.:DE268017274
District Court of Mannheim HRB 708165
CEO: Dirk Sandrock